

Replacing an Existing Temperature Probe

If the existing temperature probe has a white connector near the probe, **cut the white connector out** and solder the wires for this new probe to the existing wires. The two black wires have no polarity.